

Historical Restoration Mortar (HRM)

Mixing instructions:

All materials should be at or above 55°F. Priming: For best adhesion, do not apply product to dry surfaces- light misting is appropriate. **MIX PART B WELL BEFORE USING.** Combine the two ingredients of powder and liquid until a slurry or knife grade desired consistency is obtained. Determine the powder to liquid proportion that works and handles the best for your particular application. Use a straight edge trowel to spread the material. Lightly mist the repair mortar with clean water immediately after application. Allow to cure before carving, grinding, or shaping. Scraping HRM after 20 minutes results in a lighter appearance.

For deeper patches- Use ACR ½ fiber filler (At this point if the patch is ½ inch or deeper the filler should be added).

Approximately 1 teaspoon of fiber filler per 2 oz cups of part A powder and mix thoroughly

Then add part B liquid to powder until the mix is comparable to mortar